


EMV18-33


Conditioner:

Cleaner:

Zone Configuration



Cleaner Transition



Mode: Clean and Condition

Speed: Max Clean

Start Cleaner Spray: 0 Feet

Start Squeegee: 0 Feet

Start Conditioning: 6 Inches

Split Pattern: No

| Zone 1 | Avg | Ratio | Zone 2 | Avg | Ratio |
|--------|------|---------|--------|------|---------|
| Left | 45.2 | 1.9 : 1 | Left | 30.0 | 1.8 : 1 |
| Right | 45.2 | 1.9 : 1 | Right | 30.0 | 1.8 : 1 |
| Center | 85.0 | | Center | 55.0 | |

| Zone 3 | Avg | Ratio | Zone 4 | Avg | Ratio |
|--------|------|---------|--------|------|---------|
| Left | 21.4 | 2.1 : 1 | Left | 12.0 | 1.7 : 1 |
| Right | 21.4 | 2.1 : 1 | Right | 12.0 | 1.7 : 1 |
| Center | 45.0 | | Center | 20.0 | |

| Zone 5 | Avg | Ratio |
|--------|-----|---------|
| Left | 1.0 | 1.0 : 1 |
| Right | 1.0 | 1.0 : 1 |
| Center | 1.0 | |